LIST OF VARIATION KEYS

Use the appropriate Variation Key to knit the patterns marked "○" in the columns below.

	1 REVERSE	2 MIRROR IMAGE	3 DOUBLE WIDTH	4 DOUBLE LENGTH	5 UPSIDE DOWN	6 KHC	7 KRC
FAIRISLE PATTERN	○	○	○	○	○	○	–
TUCK STITCH PATTERN	○	△ *1	–	△ *2	○	– *3	–
SKIP STITCH PATTERN	○	○	○	○	○	– *3	–
WEAVING PATTERN	○	△ *4	△ *4	○	○	○	–
THREAD LACE PATTERN	○	△ *5	△ *5	○	○	–	–
PLATED TUCK STITCH PATTERN	○	△ *1	–	–	○	– *3	–
LACE/FINE LACE PATTERN	–	–	–	–	–	–	–
MULTI-COLOUR RIB	○	○	○	○	○	○	○ *6

*1 – Don't use the Mirror Image Key for a pattern which has more than 2 tuck stitches at the point where the patterns join. (See p. 62 Tuck Stitch Patterns.)

*2 – Use the Double Length Key according to the remarks on page 62 under Tuck Stitch Patterns.

*3 – You can knit Tuck Stitch, Plated Tuck Stitch and Skip Stitch Patterns from "STITCH WORLD" without using the KHC Key.

*4 – Don't use the Mirror Image Key for patterns which have more than 6 selected needles at the point where the patterns join. Don't use the Double Width Key for patterns which have more than 3 selected needles next to each other. (See p. 62 under Weaving Pattern.)

*5 – Don't use the Mirror Image Key for patterns which have more than 6 selected needles at the point where the patterns join. Don't use the Double Width Key for patterns which have been more than 3 selected needles next to each other. (See p. 62 under Thread Lace Pattern.)

*6 – Always the KRC Key when you knit multi-colour Rib.